





CONFIGURAÇÃO DO MODEM WIRELESS

Quando tiver acesas as luzes **Power**, **DSL** e **Ethernet** do modem siga os passos abaixo para a configuração deste (modem):

1. Na caixa do endereço (*Address*) do browser coloque o endereço <http://192.168.1.1> e faça o **Enter**



2. Aparece-lhe a Janela que se segue:
Escreva em Username: **admin** e em Password: **admin**. Clique no botão **Login**



3. Em seguida clique no botão **Wizard**

The screenshot shows a web browser window displaying the ZTE ZXV10 W300 configuration page. The address bar shows the URL `http://192.168.1.1/getpage.gch?pid=1001`. The page has a navigation menu with tabs for Wizard, Setup, Advanced, Security, Wireless, Tools, and Status. The 'Wizard' tab is selected. Below the navigation menu, there is a 'Welcome' section with a 'Logout' button. A table lists the main sections: Wizard, Setup, Advanced, Security, Wireless, Tools, and Status, each with a brief description of its function. Below this table is a 'Status Information' box containing the following details:

SW Revision: V1.0.3.U01B	DSL Status: Connected
Ethernet: Connected	DSL Speed: 512/1024 Kbps
Enable AP: Enable	SSID: BAVO

At the bottom of the page, it states 'All rights reserved by ZTE Corporation©2006'.

4. Confirma os parâmetros VPI 8 /VCI 81 e clique no botão **NEXT**

The screenshot shows the 'Wizard' step in the ZTE ZXV10 W300 configuration page. The page title is 'Wizard-->Step 1' and includes a note: 'Note:The configuration will be saved automatically.' The main content area is titled '1 Wizard' and contains the text: 'The setup wizard will set the Wireless ADSL Router step by step.' Below this, there is a section titled 'Internet access setting -- ATM PVC Setting' with the instruction: 'You can ask ISP for VPI/VCI values or may click 'Auto' to search VPI/VCI automatically (need ISP's DSLAM Support)'. The form contains three input fields: 'VPI:' with the value '8' and '(0-255)', 'VCI:' with the value '81' and '(32-65535)', and 'Auto:' with an unchecked checkbox. A 'Next' button is located at the bottom right of the form. At the bottom of the page, it states 'All rights reserved by ZTE Corporation©2006'.

5. Aparece-lhe a janela que se segue:
Escolha o **PPP Over Ethernet (PPPoE)** e Clique no botão **NEXT**

The screenshot shows the configuration wizard interface for a ZTE ZXV10 W300 device. At the top, there is a navigation bar with tabs for 'Wizard', 'Setup', 'Advanced', 'Security', 'Wireless', 'Tools', and 'Status'. Below this, a status bar indicates 'Wizard-->Step 2' and a note: 'Note:The configuration will be saved automatically.' There are 'Logout' and 'Back' buttons. The main content area is titled 'Internet access setting -- Connection Type' and features a large number '2' on the left. The text reads: 'Please ask ISP for WAN connection type and encapsulation supported.' Under 'Connection Type', there are radio buttons for 'PPP over Ethernet (PPPoE)', 'Bridge', 'PPP over ATM (PPPoA)', 'DHCP', 'Static Bridged', and 'Static Routed'. The 'PPP over Ethernet (PPPoE)' option is selected. Below this, the 'Encapsulation' is set to 'LLC/SNAP' in a dropdown menu. At the bottom right, there are 'Back', 'Next', and 'Cancel' buttons. A footer note states 'All rights reserved by ZTE Corporation©2006'.

6. Insira em PPP username **o Número do seu telefone** e em PPP password a **nova password** e clique no botão **NEXT**

The screenshot shows the configuration wizard interface for a ZTE ZXV10 W300 device, Step 3. The navigation bar and status bar are identical to Step 2. The main content area is titled 'Internet access setting -- PPP Username and Password' and features a large number '3' on the left. The text reads: 'Please enter the username and password for PPP connection which is provided by the ISP.' There are two input fields: 'PPP Username:' with the value '21456564' and 'PPP Password:' with a masked password of seven dots. At the bottom right, there are 'Back', 'Next', and 'Cancel' buttons. A footer note states 'All rights reserved by ZTE Corporation©2006'.

7. A seguir clique no botão **Submit**

ZTE | ZXV10 W300 Wizard Setup Advanced Security Wireless Tools Status 简体中文 English

Wizard-->Step 4 Note:The configuration will be saved automatically. Logout

Wizard - Summary

Make sure that the settings below match the settings provided by your ISP.

WAN Settings:

VPI/VCI	8/81
connection type	PPPoE
PPP Username	21456564
WAN IP Address	auto assigned
Default Gateway	auto assigned
DNS Server	auto assigned

Back Submit Cancel

All rights reserved by ZTE Corporation©2006

7 No *Pop Up* que aparece, Click no botão **OK**

ZTE | ZXV10 W300 Wizard Setup Advanced Security Wireless Tools Status 简体中文 English

Wizard-->Step 4 Note:The configuration will be saved automatically. Logout

Wizard - Summary

Make sure that the settings below match the settings provided by your ISP.

WAN Settings:

VPI/VCI	8/81
connection type	PPPoE
PPP Username	21456564

Microsoft Internet Explorer

After finishing the wizard, the previously saved configuration will be replaced.

OK Cancel

Back Submit Cancel

All rights reserved by ZTE Corporation©2006

8. Deixe processar até que aparecer a janela com a frase **YOU CAN ACCESS THE INTERNET NOW**



9. Por fim, clique em **File** e faça o **close** da janela que se segue:

